

## OFFICE OF THE NATIONAL COMMANDER NATIONAL HEADQUARTERS CIVIL AIR PATROL

UNITED STATES AIR FORCE AUXILIARY MAXWELL AIR FORCE BASE, ALABAMA 36112-5937

ICL 20-05 7 August 2020

## MEMORANDUM FOR ALL CAP UNIT COMMANDERS

FROM: CAP/CC

SUBJECT: Interim Change Letter – CAPR 77-1, Operation and Maintenance of Civil Air Patrol

Vehicles

1. This letter immediately changes CAPR 77-1, *Operation and Maintenance of Civil Air Patrol Vehicles* and will remain in effect until revised. Compliance with this letter is mandatory.

- 2. Add paragraph 2-1. d. that reads "Refer to the Tire Safety Checklist in Attachment 2 for additional guidance on tire inspections when completing the CAPF 73 inspection."
- 3. Add new paragraph 3-1. c. that reads "Tires, to include spare, shall be replaced according to manufacturer's tread wear guidelines and/or at least every six years based on date of manufacture. See the Tire Safety Checklist in Attachment 2 for additional guidance on determining tire age. Ensure purchased tires are the same load rating and size as recommended by vehicle manufacturer."
- 4. Delete the following sentence from the beginning of Attachment 2: "Edited from the U.S. Department of Transportation National Highway Traffic Safety Administration (NHTSA) DOT HS 809 361"
- 5. Delete "Tire Safety Checklist" in Attachment 2 on page 18. Replace with the checklist and illustration attached to this letter.
- 6. For comments or questions regarding this interim change letter, contact Gary Schneider, CAP/LG, at (334) 953-9084, or email gschneider@capnhq.gov.

MARK E. SMITH Major General, CAP

Mark & Swifts

Attachment: New Tire Safety Checklist

## **Tire Safety Checklist**

- 1. Inspect tires for uneven wear patterns on the tread, cracks, foreign objects, dry rot or other signs of wear or trauma.
- 2. Check the tire age. Replace all tires, including the spare if they were manufactured more than six years ago. (Use the graphic below to determine the age of tire.)
- 3. Remove bits of glass and other foreign objects wedged in the tread.
- 4. Make sure your tire valves have valve caps.
- 5. Check tire pressure.
- 6. Do not overload your vehicle.
- 7. Check the tire information placard or owner's manual for the maximum recommended load for the vehicle.
- 8. If you are towing a trailer, remember that some of the weight of a loaded trailer is transferred to the towing vehicle.

